

FITTING INSTRUCTIONS



CARRON
PHOENIX

BELFAST

Fitting into solid wood worktops only

Notes prior to installation:


- If you are mounting your Belfast into a granite or marble worktop you must have a fabricator cut the hole for you.
- Due to dimensional tolerances within all ceramic sinks these instructions should be used as guidelines only.
- The position of your sink will be determined by the relationship of the sink edges to cabinet gables, supports and tap location.
- Ensure current plumbing fixtures are long enough to reach the new sink and it's location.
- If unsure of fitting your sink we recommend seeking the advice of a professional fitter.

You will need:

- Electric saw with jigsaw fitment or a router
- Translucent silicone sealant

Belfast sinks should be fitted with a worktop overhang of approximately 10mm on the back and sides of the bowl and the depth of the cut out should allow the front wall of the sink to project out by half the depth of the sink wall thickness.

see image (a)



- 1 Using the internal measurements of the sink as a base, measure in 10mm from this and mark on your worktop.
- 2 Cut out the hole using a jigsaw or router. At this stage it is advisable to piece all parts of the sink and waste together to ensure their fit within the worktop. You should try to leave 5mm clearance around the sink to allow for expansion.
- 3 Fit any rails and worktop supports when satisfied with the position of the sink and waste kit.
- 4 Remove the sink temporarily to apply a bead of silicone to the base unit and to the underside of the worktop overhang, this is designed to offer additional support between the top rim of the sink and the underside of the worktop. Replace the sink in desired position and leave to set to the base unit.

